



Take Ownership of a Lockbox Using Your SentiCard

1. Renew your SentiCard using a computer and a card reader with the SentiCard Utility.
2. Insert your SentiCard into the lockbox. You'll hear chirps, and **CARD** and **CODE** will light up on the lockbox.
3. Renew your SentiCard again using a computer and a card with the SentiCard Utility.