

# Enable CBS Mode Using Your SentriCard

The Call Before Showing (CBS) code is an additional code that may be required to access a lockbox key compartment. It is used when the listing agent wants to be notified about a showing prior to the actual showing date and time. Not all lockboxes are capable of using a CBS code. You can use this feature as long as you have permission from your association.

To enable CBS mode:

1. Insert your SentriCard into the lockbox. **CARD** and **CODE** will light up on the lockbox.
2. On the lockbox keypad, enter your PIN and press **ENT**. **READY** will light up on the lockbox.
3. On the lockbox keypad, press **FUNC + 6 + 9 + ENT**. **READY** will light up on the lockbox.

To disable CBS mode:

1. On the lockbox keypad, press **FUNC + 6 + 8 + ENT**.

Use a CBS code with your SentriCard to open a lockbox:

1. Insert your SentriCard into the lockbox. **CARD** and **CODE** will light up on the lockbox.
2. Remove your SentriCard.

– OR –

On the lockbox keypad, press **FUNC + 3 + ENT**. **CODE** will begin blinking on the lockbox.

3. On the lockbox keypad, enter the CBS code and press **ENT**. The key compartment will open.